# **AutoFaucet®**

## with "Surround Sensor" Technology

500485 500484

4" Plate 8" Plate

### Automatic Faucet System

- Delivering Cost-Effective Customer Delight... provides the user water ONLY when needed, resulting in reduced water usage and associated costs
   win-win solution.
- World-Class Reliability... breakthrough "surround sensor" technology (no infrared) senses user from any angle, patented cam gear technology controls water flow and eliminates sticking solenoid valves that cause dripping -- trouble-free operation.
- Ease of Installation... all mechanical and electrical components are contained in one covered housing for easy installation -- customer convenience maximized.
- Radius™ Touch-Free Technology... systems won't corrode or fail because our proprietary cam-gear "dry" design keeps all electronics away from water flow. Technical Concepts' exclusive technologies enable our systems to be the most accurate on the market delivering error-free, precise performance and are sophisticated enough to compensate for users and the environment.

#### Kit Includes:

- Spout with 1.5 GPM Aerator
- · Valve Control Housing
- Cover plate (either 4" or 8")
- · Mounting Hardware
- · Mixing Valve with filter
- (2) Supply Hoses (3/8" x 3/8" x 12")

#### **Optional Aerators:**

401190 0.5 GPM Aerator for water savings401148 2.0 GPM Aerator for hard water

490137 Extension hose for lowering Valve Control Housing

#### Specifications

Auto/Open Valve Dial: AUTO- enables automatic operation of valve.

**OPEN**- maintains open valve position for sanitary flushing. To reactivate automatic operation, turn dial to auto position and then place hand under faucet

and remove

Battery Power: 4D cell Alkaline (up to 3+ years life cycle)

Mounting Hole: 7/8" to 11/8" Operating Water Pressure: 7-175 psi

Operating Temperature: 35°F to 159°F (2°C to 70°C)


Max Running Time: 30 Seconds



Case Pack: 1
Case Weight: 7 |

#### Operations

- 1) "Surround Sensors" continuously scan the detection zone around the spout.
- 2) When the user's hands come into range of the sensor's detection zone, the valve is activated.
- 3) After the user removes their hands, the valve closes. The circuit automatically resets for the next user.
- 4) Sensors will only detect living beings.





www.airdelights.com

9974 SW Arctic Dr Beaverton, OR 97005 Toll Free: 1-800-440-5556 Fax: 503-643-8224